INSTRUCTIONS GEI-18370-C

PRESSURE RELIEF DEVICE

FOR

POWER TRANSFORMERS



GENERAL ELECTRIC COMPANY SCHENECTADY, N. Y.

April 1945

Supersedes GEI-18370-B

THESE INSTRUCTIONS DO NOT PURPORT TO COVER ALL DETAILS OR VARIATIONS IN EQUIPMENT NOR TO PROVIDE FOR EVERY POSSIBLE CONTINGENCY TO BE MET IN CONNECTION WITH INSTALLATION, OPERATION OR MAINTENANCE. SHOULD FURTHER INFORMATION BE DESIRED OR SHOULD PARTICULAR PROBLEMS ARISE WHICH ARE NOT COVERED SUFFICIENTLY FOR THE PURCHASER'S PURPOSES, THE MATTER SHOULD BE REFERRED TO THE GENERAL ELECTRIC COMPANY.

PRESSURE RELIEF DEVICE

This pressure relief device is used on top of the main cover of power transformers for the purpose of relieving any sudden pressure such as may accompany an arc under the insulating liquid. The device is used on completely sealed, gas-seal and gas-oil-seal transformers.

The pressure relief device may be installed on a manhole cover or directly on the main cover. Refer to Fig. 1 which shows the parts of this relief device with the device flange installed on a manhole cover. The relief diaphragm (Item 2) is a thin disc of molded material (G-E compound 2029B) firmly held between clamping rings with a gasket joint. These clamping rings are the flange (Item 1, on the manhole cover and the ring (Item 3). A metal cap or cover (Item 4) provided over the diaphragm is held down by a relief pin. The underside of this cover has a grid with its edges located just above the diaphragm. A metal lid (Item 7) held in place by three guide studs is provided over the complete diaphragm assembly to protect it from the weather. Should a sudden pressure occur within the transformer tank, the relief diaphragm will be forced up against the several edges of the grid, breaking the relief pin and allowing the cap to lift. (The relief pin is designed to break at approx. 10 pounds tension). This permits the diaphragm to come against a cutting edge which immediately ruptures the diaphragm. This process also lifts the protective metal lid and the pressure is relieved. After this, the cap and protective lid drop back in place again to close the diaphragm opening, thus reducing the possibility of moisture entering the transformer tank after the diaphragm has been ruptured.

To renew the relief diaphragm after it has been ruptured it is necessary to remove the protective lid by unscrewing the three guide studs from the cover flange. Lift off the metal cap that has the relief pin in the center. Remove the clamping ring by taking out the six hex. head screws and remove the broken diaphragm. When putting in a new diaphragm (Item 2) a new gasket must be used in the flange (Item 1). Brush the gasket on both edges and one side with a thin coat of G-E compound 800 or 1276 and allow to set. They apply a fresh coat of the compound to the gasket ring in the metal flange and put the gasket in place. No compound should be used on the gasket surface which comes against the diaphragm. Put the new diaphragm (Item 2) in

place over the gasket. Remove the broken part of the relief pin from the central bar of the clamping ring (Item 3) and then bolt clamping ring firmly in place over the diaphragm. Replace the metal cap (Item 4) over the diaphragm with the edges of the grid down. Remove the broken part of the relief pin from the cap by taking out the small brass screw and washer (Item 5). Install new relief pin by inserting it through central hole in cap (Item 4) and carefully screwing it in place, using very light twisting effort on the screw. For this reason the relief pin is designed to be screwed in with the fingers.

Replace the washer and small brass screw (Item 5) to lock the relief pin. Replace the protective lid (Item 7) over the relief cap (Item 4) making sure that the treated pressboard disc (Item 6) is in place between the cap and the lid. The purpose of this disc is to provide a moisture proof covering over the head of the relief pin. Screw the three guide studs into the flange to hold the protective lid in place. Be sure the two rubber bumper washers are in place on each guide stud. Adjust the height of the three guide studs to 3 inches between the underside of the bolt and the top of the clamping ring as shown in A, Fig. 2. Tighten lock nut to maintain adjustment. One of the rubber bumper washers on each stud can be pushed down against the lid to hold lid firm.

When this pressure relief device is used on a *Pyranol transformer to be installed indoors a high metal cover is used over the pressure relief in place of the protective lid. This cover has a fluage at the top with a large round opening and a temporary plate is provided over the opening, bolted on with six screws. When the transformer is installed the temporary plate must be removed and a gas absorber or a vent pipe to the outside air should be installed on top of the cover. (Refer to B, Fig. 2). Use the six screws and lockwashers to fasten the gas absorber or vent pipe to the flange at the top of the cover.

The relief diaphragm assembly is removed for foreign shipment and a temporary cover is used over the opening. The assembly can be installed on the cover as previously explained for installing a new diaphragm. A new gasket must be used.

For domestic shipments the pressure relief device is left assembled in place on the transformer and a temporary round wood block 1-3/4" thick is placed under the protective lid. When a high metal cover is used over the relief device on a Pyranol transformer, a temporary wood block 6" long is used under the metal cover. These temporary shipping blocks must be removed when the transformer is installed and the protective lid or cover must be replaced. The recess in the center of the relief cap for the relief pin is temporarily covered with a sealing tape. This tape can be removed.

*Registered Trade-mark for G-E Askarel

When installing the transformer examine the relief diaphragm to be sure it is intact. To do this it will be necessary to remove the protective lid, or the cover if provided
for vent pipe connection. Remove the relief pin and metal
cap and examine the diaphragm. Replace the cap and relief pin
as previously explained, also replace the protective lid or
cover.

A pressure-vacuum gauge (scale 3 lbs. vac. to 5 lbs. press.) is provided at the top of completely sealed transformers. It is usually mounted on one of the top cooler tube headers or on the cover. This gauge provides an indication of the condition of the transformer tank seal. When the transformer is in service and carrying load the gauge will indicate a pressure which will vary depending on the temperature of the transformer. With the transformer out of service and at a low temperature the gauge will indicate a vacuum. When the temperature of the transformer is 25 C the gauge should show approximately zero pressure. If the gauge remains at zero under load or low temperature conditions of the transformer, a leak in the transformer seal is indicated.


The sealed type transformer is designed to be sealed at zero pressure at 25 C and under all normal conditions the pressure, plus or minus, in the tank will be well within the limits of the gauge scale, which might be reached only under extreme conditions.

The pressure relief diaphragm can be installed on the tank cover, sealing the tank, when the temperature of the transformer is approximately 10 degrees above or below the nominal 25 C. However, at the first opportunity, the tank should be vented by opening an air vent valve near the top of the tank when the transformer is at 25 C. Close air vent valve tight to seal tank. This also applies when installing the pressure-vacuum gauge if it has been removed for shipment.

REFERENCE

Pressure	Relief	Device	Parts	•••	• • • •	 • • • •	• • • •	• • • • •	• • •	Fig.	1
Details	of Press	sure Rel	lief .			 				Fig.	2

PRINTED IN U.S.A.




DISASSEMBLED MANHOLE COVER WITH PRESSURE RELIEF, FOR TRANSFORMER.

FIL ING NO.5155


£331.8

672

If You Didn't Get This From My Site, Then It Was Stolen From...



A-OUTDOOR OR INDOOR TYPE



B- INDOOR TYPE

PRESSURE RELIEF DEVICE

FIG. 2

IF YOU REQUIRE SERVICE

FAT ANY TIME you find it necessary to repair, recondition, or rebuild your G-E apparatus, there are 25 G-E service shops whose facilities are available day and night for work in the shops or on your premises. Factory methods and genuine G-E renewal parts are used to maintain the original performance of your G-E apparatus. If you need parts only, immediate shipment of many items can be made from warehouse stock.

The services of our factories, engineering divisions, and sales offices are also available to assist you with engineering problems. For full information about these services, contact the nearest service shop or sales office listed below:

APPARATUS SERVICE SHOPS

Atlanta, Ga
Baltimore 30, Md920 E. Fort Ave.
Buffalo 11, N. Y
Charleston 28, W. Va306 MacCorkle Ave., S.E.
Chicago 80, Ill849 S. Clinton St.
Cincinnati 2, Ohio
Cleveland 4, Ohio 4966 Woodland Ave.
Dallas 2, Texas1801 N. Lamar St.
Denver 5, Colo
Detroit 2, Mich
Houston I, Texas: 1312 Live Oak St.
Johnstown, Pa841 Oak St.
Kansas City 8, Mo
Los Angeles 1, Calif6900 Stanford Ave.
Milwaukee 3, Wisc940 W. St. Paul Ave.
Minneapolis 1, Minn410 Third Ave., N.
New York 14, N. Y
Philadelphia 23, Pa429 N. Seventh St.
Pittsburgh 6, Pa
St. Louis 1, Mo
Salt Lake City 9, Utah 141 S. Third West St.
San Diego 1, Calif2045 Kettner Blvd.
San Francisco 3, Calif1098 Harrison St.
Seattle 4, Wash
West Lynn 3, Mass920 Western Ave.
Youngstown 3, Ohio121 E. Boardman St.

San Francisco Los Angeles San Diago	Advantage of Coronal C
	Houston on the Carlotte Control of the Carlotte Contro

APPARATUS SALES OFFICES

Akron 8, Ohio
Albany 1, N. Y
Amarillo, Texas
Atlanta 3, Ga187 Spring St., N.W.
Bakersfield, Calif
Baltimore 1, Md39 W. Lexington St.
Bangor, Maine
Barrent Tana
Beaumont, Texas
Binghamton, N. Y
Birmingham 2, Ala600 N. Eighteenth St.
Bluefield, W. VaAppalachian Bldg.,
P.O. Box 447 Boston 1, Mass140 Federal St.
Boston I, Mass
Buffalo 3, N. Y535 Washington St.
Butte, Mont
Butte, Mont20 West Granite St. Canton 1, Ohio700 Tuscarawas St., W.
Cedar Rapids, lowa203 Second St., S.E.
Charleston 28, W. Va306 MacCorkle Ave., S.E.
Charlotte 1, N. C
Charlottesville, Va
Chattanooga 2, Tenn832 Georgia Ave
Chicago 80, III
P.O. Box 5970/s
P.O. Box 5970/. Cincinnati 2, Ohio215 W. Third St.
Cleveland 4, Ohio4966 Woodland Ave.
Columbia 23, S. C1225 Washington St.
Columbus 15, Ohio
Dallas 2, Texas1801 N. Lamar St.
Davenport, Idwa
Dayton 2, Ohio
Denver 2, Colo
Des Moines, Iowa418 W. Sixth Ave.
Detroit 2, Mich
Duluth 2, Minn
El Paso, Texas
Erie 2, Pa
Evansville 19, Ind
Fairmont, W. Va
Fergus Falls, Minn102 W. Lincoln Ave.,
P.O. Box 197
F.O. BOX 19/

AFFARAIUS	SALES	OLLICES
Fort Wayne 2, Ind	12	7 W. Berry St.
Fort Worth 2, Texas.	408	W. Seventh St.
Fresno 1, Calif	Tulare	and Fulton St.
Grand Rapids 2, Mich	.: 148 Mon	roe Ave. N.W.
Greenville, S. C	106 W.	Washington St.
Hagerstown, Md	Professi	onal Arts Blda
Hartford 3, Conn		410 Asylum St.
Houston 1, Texas	131	2 Live Oak St
Indianapolis 4, Ind	11	O N Illinois St
Jackson, Mich	120 W.	Michigan Ave
Jackson 1, Miss	203	W. Capital St
Jacksonville 2, Fla	237	W. Forsyth St.
Johnstown, Pa		841 Oak St.
Johnstown, Pa Kansas City 6, Mo	106 W.	Fourteenth St.
Knoxville 08, Tenn		02 S. Gay St.
Knoxville 08, Tenn Los Angeles 54, Calif.	21	2 N. Vianes St.
Louisville 2, Ky	45	5 S. Fourth St.
Madison 3, Wisc	1	11 S. Hamilton
Manchester, N. H		839 Elm St.
Medford, Ore2015	E.Main St.,	P.O. Box 1349
Memphis 3. Tenn		8 N Third St
Miami 32, Fla	25 S.I	E. Second Ave.
Milwaukee 3, Wisc	940 W	. St. Paul Ave.
Minneapolis 2, Minn		12 S. Sixth St.
Mobile 13, Ala	54	St. Joseph St.
Nashville 3, Tenn	234	Third Ave., N.
Newark 2, N. J		744 Broad St.
New Haven 6, Conn		129 Church St.
New Orleans 12, La		
New York 22, N. Y	570 1	exington Ave.
Niagara Falls, N. Y	2	53 Second St.
Norfolk 10, Va		.229 Bute St.
Oukland 12, Calif	407	Inirreenth St.
Oklahoma City 2, Okla	1119 N	N. Robinson St.
Omaha 2, Nebr	409 S. S	eventeenth St.
Philadelphia 2, Pa		
Peoria 2, III		.410 Main St.
Phoenix, Ariz		
Pittsburgh 22. Pa	P	.O. Box 4006
riffsburgh 22. Pa	535	Smithfield St

Portland 3, Maine477 Congress St
Portland 7, Ore920 S.W. Sixth Ave
Providence 3, R. IIndustrial Trust Bldg
Raleigh, N. C
Reading, Pa
Richmond 17, Va 8th St. Franklin St.
Roanoke 11, Va 202 S. Jefferson St
Rochester 4, N. Y
Rockford, Ill
Rutland, Vt
Sacramento 14, Calif1107 Ninth St.
St. Louis 2, Mo
Salt Lake City 9, Utah 200 S. Main St.
San Antonio 5, Texas310 S. St. Mary's St.
San Diego 1. Calif
San Francisco 6, Calif235 Montgomery St.
San Jose, Calif 177 W. Santa Clara Ave.
Seattle 11, Wash710 Second Ave.
Shrevepori 39, La:803 Jordan St.
Sioux City 13, lowa 507 Sixth St.
South Bend 11, Ind112 W. Jefferson Blvd.
Spokane, Wash
Springfield, III
Springfield 3, Mass1387 Main St.
Syracuse 2, N. Y
Tacoma 1, Wash1019 Pacific Ave.
Tampa 6, Fla
Toledo 4, Ohio420 Madison Ave.
Tulsa 3, Okla320 S. Boston Ave.
Utica 2, N. Y
Washington 5, D. C806 Fifteenth St., N.W.
Waterbury 89, Conn111 W. Main St.
Waterloo, Iowa
Wheeling, W. Va 40 Fourteenth St.
Wichita 2, Kan
Williamston, N. CTown Hall
Worcester 8, Mass507 Main St.
Youngstown 3, Ohio25 E. Boardman St.

Hawaii: W. A. Ramsay, Ltd., Honoluiu

Canada: Canadian General Electric Company, Ltd., Toronto

APPARATUS DEPARTMENT, GENERAL ELECTRIC COMPANY, SCHENECTADY, N. Y.